

GLOW1 Operating Procedure:

- 1) Turn system **On**
- 2) Remove bell jar and place samples in chamber
- 3) Replace bell jar
- 4) Press **Auto Run** button on touch screen
- 5) When completed and vented, remove bell jar
- 6) Remove samples and replace bell jar
- 7) Turn system **Off**